

FIG. 1




FIG. 2




FIG. 3





FIG. 4






FIG. 5

FIG. 6




FIG. 7

DEVICE IDENTIFIER	D 0 0 0 1
DEVICE TYPE	P 5 0 7 i
DEVICE POSITION INFORMATION	1080:0:0:8:800:200C:417A
DEVICE COOPERATION SERVICE INFORMATION	pana.com/service_x

FIG. 8




FIG. 9




FIG. 10

ELECTRONIC DEVICE 20a (dev-A)

ELECTRONIC DEVICE 20b (dev-B)




FIG. 11




FIG. 12




FIG. 13




FIG. 14





FIG. 15






FIG. 16

FIG. 17




FIG. 18

